

AMPERO PRESS

Panel



1. INPUT:
1/4" mono audio jack, for connecting your instrument.



2. EXP OUT:
1/4" TRS jack, for connecting to another device with EXP control IN jack. You can use Ampero Press for both volume and expression control at the same time.



3. OUTPUT:
1/4" mono audio jack, for connecting to one other gear.



The contents of this manual are subject to change without notice.

HOTONE



AMPERO PRESS

Passive Volume / Expression Pedal



Thank you for purchasing a Hotone product.

Scan the QR code for manuals in other languages.

感谢您购买Hotone产品，请扫描上方二维码获取其他语言说明书。

www.hotoneaudio.com

Specifications

Pot Resistance:
Volume: 100k Ohms
Expression: 10k Ohms
Dimensions: 81mm(W)*162mm(D)*51mm(H)
Weight: 430g

EXP OUT Schematic

